



Voip Setup Guide for Netcomm

NB9WMaxx

1. Open up your Web browser (EG: internet explorer)
2. Put in the following IP address into the address bar:

192.168.1.1

3. Log into the modem using the following:

i. Username = admin

ii. Password = admin

4. Click on **Voice >> SIP**

NetComm™
Integrated Access Device

Voice > SIP configuration

Enter the SIP parameters and click Apply to save the parameters and apply the voice application.

Interface name:

Local selection:

Preferred codec:

Preferred ptime:

Use SIP Proxy.

SIP Proxy:

SIP Proxy port:

Register Expire Time:

SIP domain name:

Use SIP Outbound Proxy.

Enable SIP tag matching (Uncheck for Vonage Interop).

Remote server for SIP log messages.

Voip Number and the Password given by Exetel


DispName:	VoIP Phone Number:	Auth. ID:	Auth. Password:
1 02xxxxxxxx	02xxxxxxxx	02xxxxxxxx	*****
2			

5. Type the following information :

- Interface name : **ppp_8_35 (from drop down menu)**
- Local selection : **AUS – Australia (from drop down menu)**
- Preferred codec : **G711**
- Preferred ptime : 20
- **Use SIP proxy Should be ticked**
- SIP proxy : **sip1.exetel.com.au**
- SIP proxy port : **5060**
- SIP proxy domain : **sip1.exetel.com.au**
- Register expire time : **300**
- Display Name : **VoIP Phone Number**
- VoIP phone number : **VoIP Phone Number**
- Auth ID : **VoIP Phone Number**
- Auth. Password : **VoIP Password**

Note: - *Amendments for the rest of the settings are not required.*

6. Click on **‘Apply and save all Voip Parameters’**



7. Now click on **“Management”** on the left hand side of the page and then click on **“Save/Reboot”**.
8. Now click on **“Save/Reboot”** button to save all setting and reboot the modem.